

Features

- 2 LED lights
- ON/OFF button

Modes:

- Constant light
- Fast flashing
- Slow flashing

Press ON/OFF button to turn **light on**. Press ON/OFF button again to turn **fast flashing** on. Press ON/OFF button again to turn **slow flashing** on. Press ON/OFF button again to turn **light off**.

Battery Installation:

- Take off silicon part of light.
- Remove plastic cap.
- Insert CR2032 battery. Make sure the negative sign of the battery is on the bottom.
- Put back plastic cap.
- Put back on silicon part

Battery Warning:

- Exhausted batteries should be removed properly.

CAUTION: Do not dispose of batteries in a fire. The batteries may explode or leak.

INSTRUKCJA DO LAMPKI ROWEROWEJ V0712

Właściwości

- Dioda LED
- Przycisk ON/OFF (włącz/wyłącz)

Tryby pracy:

- Stałe światło
- Szybkie miganie
- Wolne miganie

wciśnij przycisk ON/OFF aby **włączyć** lampkę. Wciśnij ponownie przycisk ON/OFF aby włączyć **szybkie miganie**.

Wciśnij ponownie przycisk ON/OFF aby włączyć **wolne miganie**. Wciśnij ponownie przycisk ON/OFF aby

wyłączyć lampkę.

Wymiana baterii:

- Ściągnij silikonową część lampki.
- Ściągnij plastikową osłonkę
- Wsadź baterię CR2032, upewniając się, że biegun ujemny jest na dole
- Nałóż plastikową osłonkę
- Nałóż silikonową część lampki

Ostrzeżenie:

- Zużyte baterie powinny być odpowiednio utylizowane.

UWAGA: Nie wrzucaj baterii do ognia

IMPORTER:

AXPOL TRADING sp. z o.o. sp.k.
ul. Krzemowa 3, Złotniki,
62-002 Suchy Las k/Poznań, Poland
Tel.: (+48) 61 659 88 01

